


Enviro-Aire








TREATMENT PLANT	TREATMENT CAPASITY (GPD)	TOTAL VOLUME (GAL)	AERATION VOLUME (GAL)	CLARIFIER VOLUME (GAL)	PRIMARY VOLUME (GAL)	BOD LOADING (LBS/DAY)	CFM
EA75 IM1530	750	1586	780	276	530	1.875	4.5

NOTE: 1. ADD 1% VOLUME FOR BAFFLES
2. ADD 1% VOLUME FOR DELTA BTW ACTUAL AND THEORETICAL VOLUME (DUE TO SAG)

NOTES:

- INSTALL ENVIRO-AIRE AREOBIC TREATMENT UNIT PER INSTALLATION INSTRUCTIONS.
- 2. INSTALL TANK PER INSTALLATION INSTRUCTIONS.
- 3. AIR COMPRESSOR INSTALLED WITHIN 100 FT OF THE TANK.





TREATMENT PLANT	TREATMENT CAPACITY (GPD)	TOTAL VOLUME (GAL)	AERATION VOLUME (GAL)	CLARIFIER VOLUME (GAL)	PRIMARY VOLUME (GAL)	BOD LOADING (LBS/DAY)	CFM
EA 52.5 IM1060	525	1122	558	181	383	1.31	2.6

NOTES:

- 1. INSTALL ENVIRO-AIRE AREOBIC TREATMENT UNIT PER INSTALLATION INSTRUCTIONS.
- 2. INSTALL TANK PER INSTALLATION INSTRUCTIONS.
- 3. AIR COMPRESSOR INSTALLED WITHIN 100 FT OF THE TANK.
- 4. FLORIDA CATEGORY 4 BRACING INCLUDES TWO (2) HORIZONTAL STIFFENERS AND FOUR (4) DIAGONAL STIFFENERS.
- 5. DIAGONAL AND HORIZONTAL STIFFENERS NOT SHOWN.



